

AC-Driver - Order # R800 7322 00



The AC-Driver™ is a compact yet powerful preamp for acoustic instruments on stage. EQ and volume adjustments provide you with complete control over your tone, in a rugged steel chassis with heavy duty components that will withstand the harshest touring environments. A variable low cut filter removes excessive low frequencies, along with a notch filter and a 180° polarity reverse switch to help eliminate feedback. The notch filter features a three position switch that allows you to select between a normal or deep notch, or remove it from the signal path altogether. A balanced XLR output feeds the PA system or a powered speaker, while a 1/4" output can be used to simultaneously connect to an amplifier. The AC-Driver also features an always-on 1/4" tuner output and a dedicated Mute footswitch, allowing for silent tuning on stage.

Features

- Studio quality preamp in a compact pedal
- Notch and low cut filters for feedback control
- Mute footswitch for silent tuning on stage

Applications

- Easily adjust levels & reduce feedback on stage
- Works with active or passive pickups
- Send your instrument output directly to the PA

Extras

- LED indicators for visual feedback
- Ground lift to eliminate buzz and hum
- Easily powered with a 9V supply

180° – Phase reverse helps fight on-stage feedback hot spots.



NOTCH - sets the center frequency for the notch filter. Used to eliminate feedback.

LOW CUT – Variable Low cut (high-pass) filter eliminates bass resonance.

1/4" OUTPUT – For the on-stage instrument amp.


MUTE – Heavy-duty footswitch silences the 1/4" and XLR outputs.

TUNER – Always-on tuner output for on-the-fly adjustments.



Feed a stage amp and FOH simultaneously

Send your acoustic signal to a stage amp and the PA simultaneously with EQ controls for both. Activate the 180° for phase corrections between your stage amp and monitors.



Feed the PA directly

Send a balanced signal directly to the PA or a powered speaker. Activate the Mute switch for silent tuning or change guitars without waiting for the FOH engineer to mute the channel.

