

FLEXUS FX100

AUDIO ANALYZER

QUICK GUIDE



PACKAGE LIST

- FLEXUS FX100 Audio Analyzer
- Mains cable
- USB cable
- FLEXUS CD (PC software and product information)
- Calibration certificate
- This quick guide



OPERATING CONDITIONS & SAFETY ADVICE

- Required mains power: 90 - 264 VAC / 47 - 63Hz.
- Maximum voltage at analog inputs: 200Vp.
- Do not apply AC voltages to analog outputs.
- Environmental conditions
 - Operating: 5°C to 45°C / 90% RH non-condensing.
 - Storage: -20°C to 80°C / 90% RH non-condensing.
- You may stack up to four FLEXUS units.
- Keep front panel ventilation inlet holes open.
- For detailed specifications see www.nti-audio.com/flexus





MAINTENANCE

- There are no serviceable parts inside.
- Clean surface with a dry cleaning cloth. You may use a mild cleaning agent if required.



INTRODUCTION

Make yourself familiar with the connections, controls and elements of your FLEXUS audio analyzer.





START OF OPERATION

1. Unpack items.
2. Install software.
 - Insert FLEXUS CD into the CD drive of your PC.
 - Open CD drive folder and double-click on setup.exe.
 - Follow installation instructions.
3. Connect FLEXUS to mains power.
4. Connect FLEXUS and PC with USB cable, using the USB-B connector.
5. Launch FX-Control.
6. FX-Control will start with a default measurement project
7. For further information on how to operate FX-Control, please use the online help via the "F1" key.



HOW TO ...


Operate the FX 100 front panel



The FX100 can be operated with the Push&Turn wheel on the front panel. It allows navigating through a menu system.

- By turning the wheel, the highlighted active item can be changed.
- By pressing on a active item, the functionality gets active.

Perform a firmware upgrade




If there is a new firmware available, FX-Control will notify you upon startup.

- Confirm and download the *fxu file to the root folder of an USB memory stick.
 - Plug the USB memory stick into one of the USB Type-A connectors of your FLEXUS unit.
 - Select the FLEXUS menu **SYSTEM** → **=VER** → **FW-UPDATE**
- Select the stored fxu file from the list.
 - The firmware upgrade will proceed automatically. This may take up to a few minutes. Do not switch off the unit during the firmware upgrade process.




Set the FLEXUS date and time



- Select the FLEXUS menu **SYSTEM** → **=TIME**
- Set the correct date and time.

Configure the headphone output



Content Source Volume

Content:

- MONITOR (the unfiltered analyzer input signal).
- PURESOUND (the bandlimited PureSound analysis input filter).

Source:

- The analyzer channel number routed to the headphone output.

Volume:

- Controls the volume from 0% to 100%

Perform a system check

- Navigate through the FLEXUS menus to **SYSTEM** → **=TST**
- The system will perform a few basic tests and return **PASSED** or **FAILED**

Determine the calibration due date

- Navigate through the FLEXUS menus to **SYSTEM** → **?CAL**
- The system will display the last calibration date, and the next calibration due date.

Get further information and support

- Register your FX100 under <http://my.nti-audio.com> for product news, firmware and software updates.
- Consult the FX100 user manual on the FLEXUS CD.
- Contact your local NTi Audio partner for technical support.

NTi Audio AG
Schaan, Liechtenstein
Phone: +423 239 60 60
info@nti-audio.com

NTi Audio GmbH
Essen, Germany
Phone: +49 201 6470 1900
de@nti-audio.com

NTi Audio UK
Stevenage, United Kingdom
Phone: +44 1438 870632
uk@nti-audio.com

NTi Audio Praha
Praha, Czech Republic
Phone: +420 2209 99992
czech@nti-audio.com

NTi Audio Inc.
Tigard OR, USA
Phone: +1 503 684 7050
americas@nti-audio.com

NTI China
Suzhou, China
Phone: +86 512 6802 0075
china@nti-audio.com

NTI Japan
Tokyo, Japan
Phone: +81 3 3634 6110
japan@nti-audio.com

NTi Audio Korea
Seoul, Korea
Phone: +82 2 6404 4978
korea@nti-audio.com