

Thank you for purchasing a RockBoard® MOD Brace!

The RockBoard® MOD Brace is a simple solution for mounting heavier MOD Patchbays to your RockBoard® pedalboard in a safe and secure fashion. The RockBoard® MOD Brace is designed to provide additional support for your MOD by reinforcing the connection to your RockBoard® pedalboard. A 3mm metal drill is required for installation.

# Installation Manual for RockBoard® MOD Brace



## Mounting

# Step 1

Remove the white rubber frame from the **RockBoard**\*'s MOD Slot and place the MOD into the mounting slot on the **RockBoard**\* pedalboard.



### Step 2

Align your MOD with the existing MOD mounting holes left and right of the MOD Slot. Alternatively, you can mount the MOD in place by screwing in the two original mounting screws a tad so the MOD cannot move sideways. Next, mark the four drilling hole positions on the front of the RockBoard® pedalboard using a pencil. Remove the MOD from the RockBoard® pedalboard mounting slot again.



### Step 3

Before drilling, check that the holes are marked correctly. Then drill the holes exactly in their marked positions using a 3 mm (1/8") metal (HSS) drill bit.



# Step 4

Turn the **RockBoard**® pedalboard upside down and place the MOD back in the **RockBoard**® s MOD Slot. Slide the **RockBoard**® MOD Brace over your MOD with the holding flaps pointed inwards and place it flush to the front of your **RockBoard**® pedalboard.



### Step 5

Using 4 of the included screws and the included wrench, tightly secure the MOD to your pedalboard. The MOD Brace will now provide added security and counteract any pushing or pulling that may be exerted on the front or back connections of your MOD. This will prevent the RockBoard®'s mounting holes from stripping.



Once finished, wire up your board and start rocking!

Note: The manufacturer reserves the right to change these specifications without notice.